

PRECISION GREENS

ZEO OR ENVIROFILL

OPTIONS

NOTE:

SIERRA PACFIC LITE



PRODUCT SPECS:

(COMPACTED)

(OPTIONAL)

FIBER TYPE:	SHAPED POLYETHYLENE
PILE HIEGHT:	1 5/8"
FIBER TOLERANCE:	MODERATE FOOT TRAFFIC
FIBER TECHNOLOGY:	U SHAPED
FIBER COLOR:	OLIVE GREEN / FIELD GREEN
THATCH COLOR:	DRY YELLOW / FOREST GREEN
TUFT GAUGE:	1/2"
STICH RATE:	14 PER 3 7/8"
FACE WEIGHT:	45 OZ / SQ YD
BACKING:	PERFORATED POLYURETHANE
TOTAL WEIGHT:	73 OZ / PER SQ YD
ROLL SIZE:	15' X 75'
ROLL WEIGHT:	570 IBS
DRAINAGE WEIGHT:	28' OF RAIN PER HOUR
SEEMING DIFFICULTY:	MODERATE



RESIDENTIAL LANDSCAPE SYSTEM

INSTALLATION STEPS:

- 1. EXCAVATE MINIMUM OF 4" SOD AND SOIL
- 2. BACKFILL WITH 2 SEPARATE 2" LIFTS OF CLASS II ROAD BASE, QUARRIED 19mm MINUS AND COMPACT TO 90%
- 3. INSTALL GRASS AS PER THE TURF DESIGN AND SEAMED WITH THE ADJACENT PIECES RUNNING IN THE SAME DIRECTION; SEEMS SHOULD BE GLUED WITH NORDOT ADHESIVE #34N2 AND SEEM CLOTH, NOT ADHISIVE TAPE
- 4. SECURE GRASS TO BASE WITH 4" GALVANIZED SPIRAL NAILS ALONG THE PERIMETER (4"-6" APART)
- 5. POWER BROOM GRASS AND ENSURE ALL GRASS FIBERS ARE STANDING.
- 4. EVENLY SPREAD 2 SEPARATE LAYERS OF INFILL; FIRST LAYER 1.5 IBS PER SQ FT AND POWER BROOM; SECOND LAYER1 IBS PER SQ FT AND FINAL POWER BROOM
- 5. ONCE GRASS IS INSTALLED TO SPEC, SEEMED, AND INFILLED, SOAK THE ENTIRE AREA WITH WATER MAKING SURE ALL INFILL HAS SETTLED INTO THE BASE OF THE GRASS

